

TIMBER SPORTS FLOOR MAINTENANCE GUIDE

GENERAL CARE & MAINTENANCE | 2025

To keep your Action timber sports floor clean, safe, non-slip and durable, follow this maintenance schedule and use only the recommended cleaning products and methods.

EVERYDAY PROTECTION

No outdoor shoes or bare feet.

Use an entrance mat and wipe feet before entering.

DAILY - DRY CLEANING

Use an anti-static mop or vacuum cleaner to remove dirt, dust and loose debris from the floor.

Note: Regularly wash mop covers to retain their static effect.

FORTNIGHTLY - WET CLEANING

1. Equipment

Use a wet mop or cleaning machine fitted with a tan or white pad.

2. Cleaning solution

Use only Bona Cleaner: 2-3 capfuls of concentrate per 10 litres of water. Available from selected Mitre 10 stores (2.5 L) or Action Floors (5 L).

3. Use minimal moisture

Do not flood the timber floor. It should be dry within approximately 10 minutes. Tepid or warm water is more effective - never hot water.

4. Scuff marks

Spot clean with Bona Cleaner Concentrate on a cloth and rub gently.

IMPORTANT - PROTECT YOUR FLOOR

NEVER use a steam mop. Steam will damage timber sports flooring.

Do not use polishes, waxes or unapproved products. Their use will void your warranty.

Do not flood the floor with water or cleaner.

QUARTERLY / 6 MONTHLY

The floor should be commercially cleaned using Bona Deep Clean Solution. Action Floors can carry out this service.

ANNUALLY / BI-ANNUALLY

We recommend a recoat using Bona Waterborne Polyurethane. Action Floors can assess and complete this service.

NEED HELP WITH YOUR FLOOR?

Book a professional clean, condition assessment or recoat with Action Floors.

Chris Dennett

021 962 620 | chris@actionfloors.co.nz

actionfloors.co.nz